

Instructions for installing repair angles



Place tape at the location of the new angle.
Present the angle and trace its outline.
If the angle does not fit perfectly, cut out the annoying excess.



Cut with a cutter following the outline.
Quickly clean the cut part using a brush and acetone.
Immediately remove the rest of the tape.



Present the plate by securing it with a screw or two to prevent it from moving.
Place quick glue on the part of the counter previously cleaned with acetone.
Affix the repair angle to the glue, taking care to align its hole and that of the plate.